


HOW TO SILENCE YOUR SMOKE ALARM


TROUBLESHOOTING

ALARM TYPE 1 240V HARDWIRED

- 1A** Identify triggered alarm to enable the network to be silenced. You must locate the alarm with the flashing red light.
- 1B** Silence the network by pushing the 'Hush' button for 3 secs on the red light flashing alarm.




- 2A** Press the side latch button on the triggered alarm to disconnect the unit from the base (leave hanging).



- 2B** Remove the 9V battery.

- 3** Drain the internal battery by pushing the 'Hush' button for 3 secs whilst the alarm is detached and hanging.
(Alarm must remain hanging to avoid reconnecting to the main power and retriggering).




Tip: Listen for a dying robot sound ... 

ALARM TYPE 2 WIRELESS LITHIUM

- 1A** Identify triggered alarm to enable the network to be silenced. You must locate the alarm with the flashing red light.
- 1B** Disable the network by pushing the 'Hush' button 6 times, a solid red light will appear.
- 1C** Wait for the red light to begin flashing then press the 'Hush' button another 6 times. A loud beep will activate to indicate the alarm has been turned off.

Note: Visibility of the red light can be difficult to see when viewing the alarm from certain angles.



Service Call Required - ensure the triggered alarm is then reported via SMS to PCA on **0447 877 012**

Please include a photo of the alarm, specify the location of the alarm and provide your home address as we may be required to attend for warranty and compliance purposes.